• • Press "Channel-increase" button or "Channel-decrease" button to switch the desired channel



Long press "Channel-increase" button for about 5 seconds, channel indicator blinks, channel selection is ineffective



Long press "Channel-increase" button for about 5 seconds, channel indicator blinks, channel selection is effective



## Mode switching





Long press Setting button for about 2 seconds, switch to manual mode



Long press Setting button for about 2 seconds, switch to automatic mode



ong press Setting button repeatedly for about 2 seconds, mode can be switched circularly



Long press Setting button for about 2 seconds, switch to random mode



#### The Current Time Setting



Long press"set ting button" for 2 seconds, switch to manual mode




Long press"Channel-decrease button"for 5 seconds, "hour mark"



esent time can be adjusted under



Press"Channel-decrease button" until the "minute mark" twinkles



Press "up button" or "down button", can adjust minute.



Press"Channel-decrease button' until the "week mark" twinkles.



Press "up button" or "down

button", can adjust hour.

Press "up button" or "down button", can adjust week.



Press "Channel-increase button" to confirm the current time.



### Self-lock function



Simultaneously press"Channeldecrease button" and "Channelincrease button" for 3 seconds



The display screen will show "lock", the self-lock function starts and the button is ineffective.



Simultaneously press "Channel-decrease button" and "Channel-increase button" repeatly for 3 seconds, self-lock function exit.



# DC447(A)/DC448(A)/DC450(A) **Timer emitter**

# **Specification**

Version No: A/o 2



### Technical Support

- Input voltage: 3V(CR2430)
- Transmitting frequency: 433.92MHz
- Transmitting power: 10 milliwatt ■ Operating temperature: - 20°C ~ + 55°C
- Transmssion distance: 200 meters open office
- 1. Up button: Control motor upward and Time increase
- 2. Down button: Control motor downward and Time decrease
- 3. Stop button: Control motor stop and Exit time set
- 4. Channel-decrease button; control the decrease of channels and time setting 5. Channel-increase button: control the increase of channels
- and switch timer function workable or unworkable
- 6. Setting button: Setting button( R type motors workable) and Mode adjustment.

DC447, DC448, DC450 are five-channel timer emitter, a number within the circle showed on LCD represents one channel. Press "Cha nnel-increase' button and "Channel-decrease" button can switch the channels. And so on, press "Stop buttonwhen switched to the desired number

then this channel will be the present channel. Like 1 2 3 4 5, the present channel will be 2nd channel.

DC447,DC448,DC450 are 50\*50 case series,DC447A,DC448A,DC450A are 86\*86 case series. 1 When the LCD shows 12345, it means "Group control" channel. Operations of group control are listed as below:

1)23(4)5) channel—Group control button can control the motors of all the channels running. Group control timing is not workable. Manual mode under Group control(

(1)(2)(3)(5)) channel—Group control button can control the motors of all the channels running, when the channel is not selected Automatic mode under Group control( as effective (please refer to effective channel selection). Timing function is not workable when the channel is selected as eff ective (please refer to effective channel selection). Timing function will control the motors on time.

Random mode under Group control( 1)23(4)5) channel---Group control button can control the motors of all the channels running. Timing function is not workable when the channel is not selected as effective (please refer to effective channel selection). Timing function is workable when the refer to effective channel selection). Timing function can control the motors randomly with +-15 minutes. e channel is selected as effective (please

(1 ②345 ), it means Channel 2 is a Common channel. Operation of the Common channel are listed as below: 2 When LDC be switched to show one number within the circle Manual mode under Common channel----The buttons can control the motor running under this channel Timer function is not workable

Automatic mode under Common channel—The buttons can control the motor running under this channel. Timing function is not workable when the channel is not selected as effective (please refer to effective channel selection). Timing function is workable when the channel is selected as effective (please refer to effective channel selection). Timing function will control the motors on time.


 $Random\,mode\,under\,Common\,channel\\ -- The\,buttons\,can\,control\,the\,motor\,running\,under\,this\,channel.\\ Timing\,function\,is\,not\,workable\,when\,the\,channel\,is\,not\,selected\,as\,effective\,channel\,is\,not\,s$ (please refer to effective channel selection). Timing function is workable when the channel is select ed as effective (please re fer to effective channel selection). Timing function can control the motors randomly with +-15 minutes.

Note1: The time duration between Upward timer setting and Downward timer setting should be more than 32 minutes, or there will be errors (Erol) on the LCD when the emitter under Automatic mode and Random mode. Timer function is unworkable at the same time, and the system will exit from Setting stat Note2: There is no timing setting under Group control channel



## **Technical Support**

DC447







Eech channel can set timer function separately



Press "setting button" for 2 seconds to switch to Auto mode or Random mode.



Press "Channel-decrease button" for 5 seconds, the up timing time



Press "Channel-decrease button" again, the up timing time



Press "up button" or "down button" to adjust the timing



Press "Channel-decrease button" the up timing time (minute mark) of this channel twinkles.



Press "up button" or "down button" to adjust the timing time (minute mark) of display



Press "Channel-decrease button", the up timing time ( week mark) of this channel twinkles.



Press "up button" or "down button" to adjust the timing time (week mark) of display



Press"Channel-increase button" to confirm the up timing time of this channel. In the meantime the down timing time/hour mark) twinkles.



Press "up button" or "down button" to adjust the timing time (hour mark) of display



Press "Channel-decrease button", the down timing time (minute mark) of this channel




Press "up button" or "down button" to adjust the down timing time (minute mark) of




Press"Channel-increase button to confirm the down timing time of this channel. In the meantime mark) twinkles.



Press "stop button", exit the adjustment of the timing time and back to present channel and present time.








programming key

Press the receiver

programming key

Switch on



limit button of

Press the UP

limit button of

transmitter



One receiver store 20 emitters channels at most, and one channel of emitter can control 20 receivers at most.

One receiver store 20 emitters channels

See green indicator flashing and

extinguished

at most, and one channel of emitter can

control 20 receivers at most.




button to see the

receiver indicator



See indicator flashing



Press the STOP

indicator flashing button of receiver

See the receiver

green indicator of long flashing



