



DC50 Receiver Specification

Version NO.: A/oo



Receiver specification

support




DC50 receiver

Maximum output power: 500W One DC50 receiver can store maximum 20 emitter channels. If there are already 20 channels, it will take turns to Cover the last channel.

1) When emitter is under group control, match code will be invalid.



(2) When receiver is in dot-move mode, press up or down button within 2 seconds, motor will be controlled to operate in Dot-move mode; if keep pressing over 2 seconds, motor will continuously work.



35M

433.92MHz

868MHz

230V/50Hz

120V/60Hz

200m

200m



Black=Down


Blue=Common

Green/Yellow=Earth Blue=Neutral

Green/Yellow=Earth

Brown=Up

Brown=Live



The best installation distance




The shortest distance between receiver and ground ≥1.5m The shortest distance between receiver and roof a o.am

3 The shortest distance between receiver and receiver ≥0.2m

Setting up

During the settings, the time between two operation must be shorter than 6s, otherwise it will quit the setting





Add Emitter



Emitter a is the one already passed matching code, emitter b is the one has not

OK

The down bu-


tton control the

motor clockwise.

After matching code for

new emitter, it will clear all the data in receiver.

During the settings, the time between two operation must be shorter than 6s, otherwise it will quit the setting





Light adjust function



Repeat setting,

During the settings, the time between two operation must be shorter than 6s, otherwise it will quit the setting






Cancel emitter



Cancel emitter setting is to clear all the data



During the settings, the time between two operation must

be shorter than 6s, otherwise it will quit the setting