

Press the stop button,

Press the set button (P2) of the emitter

the motor will buzz once once, the motor will buzz several times

Press the set button (P2)of emitter


once ,the motor will buzz once

Switch on




Group control channel match code is unworkable.


DC74 A Control System Specification




Version NO.: A/00

cancel emitter is ok








35m

120V/60Hz

200m

Control System





- The shortest distance between receiver and ground ≥1.5m
- 2 The shortest distance between receiver and roof ≥0.3m
- 3 The shortest distance between receiver and receiver ≥0.2m