


**A**


## Receiver installation

Additional Function

**A**


## Set up

Additional Function

**A**


## Add Emitter

Additional Function

**A**


## Dot-move setting

Additional Function

**A**

## Cancel Emitter

Additional Function



CE

All controls support 433MHz &amp; 868MHz

All controls support 230V/50Hz &amp; 120V/60Hz

## Control System

### DC73A Control System

#### Specification

Version NO.: B/01

**T**

### Technical Support

- 1.** = × 5



One channel of emitter can control 20 receivers at most at the same time.

- 2.** DC73A Receiver

One DC73A Receiver maximum can store 20 channels, over 20 channels, if still need add new channels, it will be repeating covered in turn from the second channel.

**!** In the process of set up emitter and DC73A receiver, After the success of each set, tubular motor beep several times, then tubular motor move clockwise and counterclockwise one time as remind.  
Receiver in the mode of dot function, press up key and down key within 2 seconds, emitter control motor working in dot function; if continuous press more than 2 seconds motor will last working.  
Group control channel match code is unworkable.

### Control Range



L1 Open	L2 Partition	Emission frequency
230V/50Hz	200m	35m
120V/60Hz	200m	35m

### Matchable emitter

#### Technical Support




### Matchable tubular motor

**T**

### Circuit installation

#### Technical Support



### The best installation distance



- 1 The shortest distance between receiver and ground ≥1.5m
- 2 The shortest distance between receiver and roof ≥0.3m
- 3 The shortest distance between receiver and receiver ≥0.2m