A
Additional Function

Clockwise rotation Limit swith setting



230V / 50Hz
110V / 60Hz
power

1

Turn on the power supply



2

Press the UP button in the DC270, the motors will rotate in a clockwise direction or stop

3

Press the Program button in the DC270, the motors will rotate in a clockwise direction,Release the Program button namely confirm clockwise limit position

Repeat step 3 namely can accurate setting clockwise limit position

A
Additional Function

Counter-clockwise rotation Limit swith setting



230V / 50Hz
110V / 60Hz
power

1

Turn on the power supply



2

Press the DOWN button in the DC270, the motors will rotate in a Counter-clockwise direction or stop

3

Press the Program button in the DC270, the motors will rotate in a Counter-clockwise direction,Release the Program button namely confirm Counter-clockwise limit position

Repeat step 3 namely can accurate setting reverse limit position

Wired

CE

All controls support 230V/50Hz & 120V/60Hz

B: Button Electronic
Limit-setting switch

AC TUBULAR MOTOR

DC270(A) Limit-setting switch
Specification

Version No. : A/00

T
Technical Support

Setting limit switch method

Setting limit switch method 1



Press the button and work with the rebounded switch to set the up and down limit switch position.

DC59
Single manual switch (mechanic)

Setting limit switch method 2



Set the up and down limit switch position with the special limit switch setting button, then disassemble the limit switch setting button after the set is finished, and assemble the normal rebounded switch.

DC270
Limit-setting switch

T
Technical Support

Circuit installation



White = Grayness
Blue = Blue
Black = Black
Brown = Brown
Green / Yellow = Green / Yellow

Attention